




OPERATING INSTRUCTIONS FOR STEEL POWER SILHOUETTE CHAIR

MODEL #5432




TO ADJUST HEIGHT:

MOVE THE HEADREST UP ONE NOTCH AT A TIME TO LOCK IN ONE OF 5 AVAILABLE POSITIONS. TO LOCK IN TOP POSITION PUSH HEADREST BACK INTO SEAT BACK. TO LOWER HEADREST RAISE TO TOP POSITION, TILT FORWARD AND THEN LOWER TO THE FIRST POSITION.




TO ADJUST SIDE EXTENSIONS:

REACH BACK AND PULL EACH SIDE EXTENSION TOWARDS YOUR EARS. THIS ADJUSTMENT WILL PROVIDED TOTAL SUPPORT FOR YOUR HEAD AND NECK AND RELIEVE TENSION IN YOUR SHOULDERS AND BACK. TO MOVE SIDE EXTENSIONS BACK INTO CHAIR CUSHION, PUSH EACH SIDE EXTENSION AWAY FROM YOUR EARS UNTIL THEY ARE FLAT WITH THE REST OF THE HEADREST.



TO ADJUST FORWARD OR BACKWARD:

PULL HEADREST FORWARD FROM THE TOP OF THE HEADREST TO ANY DESIRED POSITION. TO MOVE HEADREST OUT OF THE WAY PUSH HEADREST BACK AND IT WILL MOVE BACK INTO CUSHION.




ROTATE KNOB FORWARD TO UNLOCK SEAT BACK FOR FREE FLOAT MOTION. ROTATE KNOB BACKWARD TO LOCK SEAT BACK IN ANY DESIRED POSITION.

LIFT LEVER TO SLIDE SEAT CUSHION FORWARD OR TO SLIDE SEAT CUSHION BACKWARD

LIFT UP HANDLE TO RAISE OR LOWER THE CHAIR

ROTATE KNOB FORWARD TO TIGHTEN TENSION ON SEAT BACK WHEN IN FREE FLOAT. ROTATE KNOB BACKWARD TO EASE TENSION ON SEAT BACK WHEN IN FREE FLOAT. PULL KNOB OUT FOR EASY ADJUSTMENT.

TURN RIGHT KNOB CLOCKWISE TO EXTEND LUMBAR OUT OR COUNTER CLOCKWISE TO MOVE LUMBAR BACK INTO THE SEAT



ARM PADS WILL SWIVEL EITHER LEFT OR RIGHT, SLIDE FORWARD AND BACKWARD

LIFT THE SMALL LEVER TO RAISE OR LOWER ARM

MOVE THIS LEVER TO MOVE ARM CLOSER TO OR FARTHER AWAY FROM SEAT CUSHION

TO LOCK ARM PADS IN PLACE AND PREVENT ARM PADS FROM SWIVELING JUST PUSH THE ARM PADS BACK AS FAR AS THEY WILL GO, THIS LOCKS THE PADS IN PLACE.